06-10-2025 Complete Guide: Setting Up Wi-Fi, Fixing Connectivity Issues, Configuring a PC as a Server, and Checking UDM Pro Network Details

1. How to Enable Wi-Fi on a New Laptop

Setting up Wi-Fi is one of the first things you'll do on a new laptop. The process is straightforward and guided by the operating system's initial setup wizard.

During the Initial Windows Setup (Out-of-Box Experience)

- 1. **Power On:** Turn on your new laptop for the first time. The Windows setup process will begin automatically.
- 2. **Region and Keyboard:** You will be asked to select your country or region and confirm your keyboard layout.
- 3. **Network Connection Screen:** The setup will display a screen titled "Let's connect you to a network." It will automatically scan for and list all available Wi-Fi networks in range.
- 4. **Select Your Network:** Click on the name of your home or office Wi-Fi network from the list.
- 5. **Enter Password (Security Key):** A field will appear asking for the network password. Carefully type in your Wi-Fi password. If you want to double-check it, click the small eye icon in the password box to reveal the characters.
- 6. **Connect:** Click the "Next" or "Connect" button. The laptop will verify the password and establish a connection. Once connected, it will display a "Connected, secured" status next to the network name.
- 7. **Complete Setup:** With the internet connection active, you can now proceed with the rest of the Windows setup, which includes signing in with or creating a Microsoft account.

Enabling Wi-Fi from the Windows Desktop (If Skipped During Setup)

If you skipped the Wi-Fi setup or need to connect to a different network, follow these steps:

- 1. **Open the Quick Settings Panel:** Click the network icon (which may look like a globe if not connected, or a Wi-Fi symbol) in the bottom-right corner of the taskbar.
- 2. **Ensure Wi-Fi is On:** In the panel that opens, there will be a button for Wi-Fi. If it's grayed out or off, click it to turn it on. It should turn blue.
- 3. **Select a Network:** Once enabled, the laptop will scan for networks. Click the > arrow next to the Wi-Fi button to see a list of available networks.
- 4. **Connect and Enter Password:** Click on your desired network, ensure the "Connect automatically" box is checked if you wish, and click "Connect." Enter the password when prompted and click "Next."

2. How to Fix a Missing Wi-Fi Option (Especially After Using Airplane Mode)

It can be alarming when the option to turn on Wi-Fi completely vanishes. While Airplane Mode is designed to turn wireless radios off, a software glitch can sometimes prevent them from reappearing.

Step 1: Basic Checks

- 1. **Toggle Airplane Mode:** Turn Airplane Mode on, wait about 10 seconds, and then turn it off again. This can often reset the wireless adapters correctly.
- 2. **Physical Wi-Fi Key:** Many laptops have a dedicated key or a function key combination (e.g., Fn + F5, or a key with an antenna symbol) that physically disables the Wi-Fi card. Ensure you haven't accidentally pressed it.
- 3. **Reboot the Computer:** A simple restart is the most effective fix for temporary software glitches. Power down your laptop completely and turn it back on.

Step 2: Windows Troubleshooting Tools

1. Run the Network Troubleshooter:

- Go to Settings > System > Troubleshoot > Other troubleshooters.
- Find Network and Internet and click the Run button.
- Follow the on-screen prompts. The troubleshooter can automatically re-enable adapters, restart services, and fix common configuration issues.

Step 3: Check the Network Adapter's Status

- 1. **Open Network Connections:** Press the Windows Key + R to open the Run dialog. Type ncpa.cpl and press Enter.
- 2. **Find Your Wi-Fi Adapter:** This window shows all your network hardware. Look for an icon labeled "Wi-Fi."
- 3. **Enable the Adapter:** If the icon is grayed out and says "Disabled," right-click on it and select **Enable**. This will digitally switch the adapter back on.

Step 4: Investigate Device Manager (The Most Common Fix)

The Device Manager tells you if Windows is communicating properly with the Wi-Fi hardware.

- 1. **Open Device Manager:** Right-click the Start button and select **Device Manager**.
- 2. Expand Network adapters: Click the arrow next to "Network adapters" to see the list.
- 3. **Locate Your Wireless Adapter:** Look for an item with "Wireless," "Wi-Fi," or "WLAN" in its name (e.g., "Intel(R) Wi-Fi 6 AX201").

- If it has a small down-arrow icon: The device is disabled. Right-click it and select Enable device.
- If it has a yellow exclamation mark: There is a driver problem. Right-click and select **Update driver**, then choose "Search automatically for drivers." If that fails, right-click again, select **Uninstall device** (do **not** check the box to delete the driver software), and then restart your computer. Windows will automatically reinstall it.
- If the adapter is not listed at all: The hardware is not being detected. From the top menu, click Action > Scan for hardware changes. If it still doesn't appear, it could indicate a hardware failure.

3. How to Set Up a PC as a Server

Transforming a spare PC into a server is a fantastic way to host files, run a media center, or host a website.

Phase 1: Installation

- 1. Choose a Server Operating System (OS):
 - Ubuntu Server (Recommended for Beginners/Versatility): A powerful, stable, and widely supported Linux-based OS. It is free and has a massive community for support.
 - **Windows Server:** A good option if you are already comfortable with Windows and need to integrate with Microsoft products. It has a graphical user interface but typically requires a paid license.
- 2. **Backup Your Data:** The installation process will erase everything on the PC's hard drive. Back up any important files.

3. Create a Bootable USB Drive:

- Download the installation file (ISO) for your chosen OS from its official website.
- Download a tool like **Rufus** or **balenaEtcher**.
- Plug in a USB drive (8GB or larger).
- Use the tool to flash the downloaded ISO file onto the USB drive, making it bootable.

4. Install the OS:

- Plug the bootable USB into the PC you want to use as a server.
- Turn on the PC and enter the BIOS/UEFI menu (usually by pressing F2, F12, or Delete during startup).
- Configure the boot order to prioritize the USB drive.
- Save and exit the BIOS. The PC will now boot from the USB and start the OS installation wizard.

• Follow the on-screen instructions, which will include language selection, keyboard layout, and disk partitioning (it's safe to let the installer use the entire disk).

Phase 2: Initial Configuration

- Update the System: Once the OS is installed, the first step is to update all software
 packages. For Ubuntu Server, the command is: sudo apt update && sudo apt upgrade v
- 2. **Set a Static IP Address:** A server's IP address should not change. You need to configure a static IP from within your router's settings.
 - Log in to your router's admin page (usually at 192.168.1.1 or 192.168.0.1).
 - Find the DHCP or Address Reservation settings.
 - Assign a permanent IP address (e.g., 192.168.1.100) to your server's MAC address.
- Enable Remote Access (SSH): You won't want a monitor and keyboard attached to your server forever. SSH (Secure Shell) lets you manage it remotely from the command line of another computer.
 - During the Ubuntu Server installation, you are given an option to install the OpenSSH server. If you missed it, install it with: sudo apt install openssh-server

Phase 3: Security Hardening Steps

- 1. **Configure the Firewall:** A firewall is your first line of defense.
 - On Ubuntu, use UFW (Uncomplicated Firewall).
 - Enable it: sudo ufw enable
 - Allow essential services, like SSH: sudo ufw allow ssh
 - If you set up a web server, you'll need to allow web traffic: sudo ufw allow http and sudo ufw allow https.
- 2. **Use Strong Passwords:** Ensure the user accounts on the server have complex, unique passwords.
- 3. **Regularly Update:** Keep your system secure by regularly running the update commands mentioned in the configuration phase.
- 4. **Manage User Permissions:** Avoid using the main root account. Operate from a standard user account with sudo privileges for administrative tasks.

4. How to Check the UDM Pro IP Address and MAC Address

The Ubiquiti UniFi Dream Machine Pro (UDM Pro) is a powerful network appliance. You can find its device information in several ways.

Method 1: Using the UniFi Network Application (Web Browser)

This is the most common method for network administrators.

- 1. **Log In to Your UniFi Controller:** Open a web browser and navigate to the IP address of your UDM Pro, or log in via unifi.ui.com.
- 2. **Navigate to Devices:** Once on the dashboard, click on the **UniFi Devices** icon on the left-hand menu (it looks like a small UDM).
- 3. **Select the UDM Pro:** A list of all your UniFi devices will appear. Click on your UDM Pro.
- 4. **View the Properties Panel:** A panel will slide out from the right side of the screen.
- 5. Find the Information:
 - **IP Address:** The local IP address is displayed prominently near the top of the panel.
 - **MAC Address:** Click on the **Details** tab within this panel. You will find the MAC address listed there, often under a "Details" or "General" section.

Method 2: Using the UDM Pro's Front Panel Touchscreen

The UDM Pro has a small LCD screen for at-a-glance information.

- 1. **Wake the Screen:** Touch the screen to wake it up.
- 2. **Navigate the Menu:** Swipe through the different status screens.
- 3. **Locate Network Info:** One of the screens will display general status and network information, which includes its current WAN and LAN IP addresses. The MAC address is also typically available in the device details section on the screen.

Method 3: Using the UniFi Network Mobile App

- 1. **Open the App:** Launch the UniFi Network app on your smartphone or tablet.
- 2. **Connect to Your Controller:** Ensure you are connected to the correct UDM Pro controller.
- 3. **Tap the Devices Icon:** On the bottom navigation bar, tap the **Devices** icon.
- 4. **Select the UDM Pro:** Tap on the UDM Pro from the list of devices.
- 5. **View Details:** The device's primary information, including its IP address, will be displayed. You may need to tap into a "Details" or "Information" section to see the MAC address.